

Location	External Loading Dock/ Trailer Park	Revision	2
Process / Task	Extender Trailers	Document no.	RA SWP TAT 023
Required Equipment & Materials		Last Review Date	12/06/2023
Persons involved	Driver/ Shunter	Expiry Date	11/06/2025
Mandatory Training		Reference Documents	RA SWP TAT 003
Author	Bill McCormack	Approver	Claire Reynolds

	(D)	, F		A CONTRACT	ent			0					
we live by	Fundamentals		lestrian tection	Working at height	Equipment	High Visibility	Gloves	Hearing Protection		Asphyxiation	Collision – mobile equipment	Crushed between objects	Entanglement
	\checkmark		\checkmark	√	tion	\checkmark	✓				\checkmark	\checkmark	√
Commitments	DYA.			, A	Personal Protection	0		0	Hazards				
	Mobile Equipment	Energy	/ Isolation	Handling Loads		Helmet	Safety Footwear	Eye Protection	-	Fall from height	Manual tasks	Slips, trips or fall at same level	Struck by falling objects
	\checkmark					\checkmark	√			\checkmark	\checkmark	✓	\checkmark
Tal 1) 2) 3) 4) 5)	 Assess the risk Take appropriate action This includes: Unsafe work; Unsafe acts and conditions; A 						Struck by mobile equipment	Struck by object	Release of energy	Human Behaviour			
			You are	empowered to ex	xerci	ise your St	op Work A	uthority		\checkmark	\checkmark	\checkmark	\checkmark
It is	the duty of all em	ployees	to comply	with the following	Saf	e Working F	Procedure d	esigned to	prov	ide a code of go	ood practice an	d conduct with t	he objective

of preventing accidents or harm. At all times employees must work in a safe manner both to prevent personal injury to themselves or others.





Attention Points SWP- TAT 023	Action
PPE / Equipment	Wear PPE
Fall from Height	3 points of contact
Struck by Mobile	Stand clear
Equipment	Remain visible
	Cone off area
Struck by Falling Objects	Stay clear of loose equipment

tep Process Io.	Attention / Risk Points	Containment action(s)	Pictures
 There are several different many of extender trailers with different mechanisms. P&O Ferrymasters do not own et trailers, however, P&O Ferrymasters may be required to operate thes for certain hauliers on customer This SWP aims to provide guidate the basics of opening up an extent trailer but everyone must refer thauliers own guidance which accompanies this document. 	we can operate are:oPrestonstenderoters staffotrailersosites.ooce onGordonsnderTransport	Any other trailers must not be operated by our staff.	





Step No.	Process	Attention / Risk Points	Containment action(s)	Pictures
2	 There are two main types of opening up the trailer. One uses the red airline to connect to the trailer to disconnect the locking pins and one has a button release:- Couple up to the trailer as normal, and wind legs up etc Make sure there is enough room free at the front of the vehicle and trailer to move forward the desired length, in a straight line. Ensure there are no people in the vicinity. Then do one of the two below options in terms of releasing the locking pins: Remove the red airline and connect to the connection point immediately to the left of the original coupling, this disconnects the locking pins 	 Fig. 1 – Risk of collision with other users in the area. Risk of trailer de- coupling. Risk of muscle strains winding landing legs up. Risk of trapping between trailers when accessing the park brake. Risk of slips, trips and falls due to ground conditions. Risk of falling from height off the catwalk. Risk of sudden release of air. 	Keep regular observation of the working area. Make others aware of intentions where possible. If possible, cone off the area. Ensure the 5 th wheel locking arm has engaged correctly and apply the locking pin/ dog clip. Controlled movement of locking arm not pull or push with excessive force. Ensure locking arm is serviced regularly Apply the trailer brake (ensure you are familiar with the different types of park brake controls). Check for potholes, spillages. PPE – Safety Helmet and chinstrap, gloves, safety boots. Always use 3 points of contact. Ensure airlines are correctly aligned and in a controlled manner uncouple from normal road coupling.	Fg. 1
3	OR Locate the locking pin control (Yellow button usually or lever or Black button as per Figs 2 and 3) and pull it out / turn it to release the locking pin.	Fig. 2 – Risk of slips and trips and falls due to ground conditions.	PPE – Safety boots and gloves. Check for potholes, spillages.	Fig. 2





Step No.	Process	Attention / Risk Points	Containment action(s)	Pictures
4	Check the area is clear, then drive forward in a straight line until the trailer is open to the approximate length desired. (Do not wait until it hits the end stops).	Fig. 3 - Risk of collision with other users in the area. Risk of trailer de- coupling. Risk of sudden release of energy/ tension in locking pin.	Keep regular observation of the working area. Make others aware of intentions where possible. If possible, cone off the area. If there is no movement, try reversing, as the locking pin maybe under tension and unable to move freely.	Fig. 3
5	Apply the tractor parking brake, RED Button, switch off the engine and remove the keys, before accessing the catwalk, using three points of contact and all steps and handrails. Then either remove the red airline and replace it back in its original position or press in the release button. The pins now try to connect but cannot do so.	Fig. 4 – Risk of falling from height off the catwalk. Risk of sudden release of air from airline. Risk of being struck by objects stored on catwalk or rear of truck cab.	PPE – Safety Helmet and chinstrap, gloves, safety boots. Always use 3 points of contact. Securely store loose equipment at rear of cab. Ensure airlines are correctly aligned and in a controlled manner uncouple from normal road coupling. Drive slowly backwards or forwards until you hear the pins engage. Carry out a tug test, moving backwards and forwards slowly to confirm the pins are engaged.	Fig.4
6	There are some very old mechanical versions still in circulationPosition trailer on even ground and align the 5th wheel so truck and trailer are level	Fig. 5 – Risk of slips, trips and falls from same level due to ground conditions.	PPE – Safety Boots. Ensure area is clear of any obstacles/ hazards before starting.	Fig. 5





Step	Process	Attention / Risk Points	Containment action(s)	Pictures
<u>No.</u> 7	Apply park brake	Fig. 6 - Risk of trapping fingers in mechanism.	PPE – Gloves. Ensure fingers are kept clear of trapping points.	Fig. 6
8	Release safety clip and locking arm	Fig. 7 & 8 – Risk of trapping fingers in mechanism.	PPE – Gloves. Ensure fingers are kept clear of trapping points.	





Step No.	Process	Attention / Risk Points	Containment action(s)	Pictures
9	Pull the handle and twist to lock it into position.	Fig. 9 – Risk of trapping fingers in mechanism.	PPE – Gloves Ensure fingers are kept clear of trapping points.	Fig. 9
10	Check the area is clear, then drive forward in a straight line until the trailer is open to just past the approximate length desired. Apply handbrake and exit the cab to check the length is correct and gauge which hole is needed on the extended neck of the trailer Release locking pin by pulling handle so it is sitting on the extended neck.	Fig. 10 – Risk of de- coupling if extender neck travels too far. Risk of trapping fingers in mechanism.	PPE – Gloves Ensure fingers are kept clear of trapping points	Fig. 10





Step No.	Process	Attention / Risk Points	Containment action(s)	Pictures
11	 Enter cab and reverse back slowly and wait for the locking pin to connect into the hole. Do visual check by looking at the nut protruding through the pin. Once happy the pin is located, re-apply the locking arm and safety clip. 	Fig. 11 - Risk of trapping fingers in mechanism.	PPE – Gloves Ensure fingers are kept clear of trapping points	Fig.11





RISK ASSESSMENT					
Hazard	Who/what can be harmed	Likelihood	Severity	Risk Level	Existing Control Measures
Lone Working - If working alone and injury occurs, potential for serious consequences	Driver/ Shunter	1	4	4	Always book in or sign in at place of work, ensure colleagues or site staff know where you are.
Trapping of fingers, operating locking arm, dog clip	Driver/ Shunter	2	2	4	PPE - Gloves,
Slips, trips and fall (from height) height of tractor catwalk, icy conditions	Driver/ Shunter	2	3	6	PPE - Safety boots, Helmet with Chin Strap, always maintain 3 points of contact. Clear catwalk of ice and snow in winter
Slips, trips and falls (same level) Ground conditions.	Driver/ Shunter	2	4	8	PPE - Safety boots, Helmet & Chin Strap.
Manual handling, potential for muscle and ligament strain, operating the locking arm, trailer leg winding handle	Driver/ Shunter	3	4	12	Controlled movement of locking arm not pull or push with excessive force. Ensure locking arm is serviced regularly. PPE - Safety boots, Helmet & Chin Strap.
Fall from height – exiting/ accessing cab, dismounting the catwalk	Driver/ Shunter	3	4	12	PPE - Safety boots, Helmet & Chin Strap., always maintain 3 points of contact. Ensure catwalk is free from debris and loose equipment. Be aware of back edge of trailer.
Struck by Objects – loose equipment stored at rear of cab (straps/ ratchets/ roof pole)	Driver/ Shunter	2	2	4	PPE – Safety Helmet Securely store loose equipment at rear of cab
Struck by mobile equipment	Driver/ Shunter/ Other visitors to area	2	3	6	PPE – Hi-viz. Be Seen, Be clear, Stay Clear





Com	Competence Check									
#	Question	Answer		#	Question	Answer				
1	What PPE is required to work on the Catwalk?			3						
2	Explain the two main types of extending trailers			4						

Sign off	Name	Signature	Date
Worker / Operative			
Trainer / Supervisor			

